


Earthquake®

2-Person Power Earth Auger Operator's Manual



Includes Model
9800



REGISTRATION AND WARRANTY

THANK YOU . . .

for purchasing an Earthquake Earth Auger from Ardisam, Inc. We guarantee that this auger conforms to applicable North American safety standards, and have worked to ensure that it meets high standards for usability and durability. With proper care, your auger will provide many years of service. Please take the time to read this manual carefully to learn how to correctly operate and maintain your auger. Congratulations on your investment in quality.

CONTENTS

Registration/Warranty	2
Safety	3
Operation	4-5
Maintenance & Storage	6-7
Service, Troubleshooting, and Repair	8-11

MODEL IDENTIFICATION

Your earth auger has a serial number decal located on engine directly above the carburetor. Engine serial number is located on opposite side of engine next to oil fill tube. Write these numbers and the model number in the space provided. You will need these numbers if you order parts.

Model Number _____

Serial Number _____

Engine Serial Number _____

Date of Purchase _____

Place of Purchase _____

One Year Limited Warranty

The Ardisam, Inc., Manufacturing Company warrants this Earthquake Model 9800 Auger to be free from defects in material or workmanship. Conditions of this warranty include:

What is covered under warranty:

Ardisam, Inc. will repair or replace any part defective in workmanship or material within one year after delivery of the auger to the original purchaser.

What is not covered under warranty:

This warranty applies only to products which have not been repaired or altered outside our factory. It covers only defects resulting from normal use, and does not cover defects arising from misuse, alteration, negligence, commercial use, or accident. This warranty applies only to the original purchaser, and is not transferrable.

How to obtain service:

Return the product to us at the address below with transportation charges prepaid.

This warranty supersedes all other warranties either expressed or implied and all other obligations or liabilities on our part. Ardisam, Inc., does not assume, and does not authorize any other person to assume for us, any liability in connection with the sale of our products. This guarantee is void unless warranty card is properly filled out and returned to Ardisam, Inc., Cumberland, Wisconsin, at time of purchase.



ARDISAM, INC.

1690 Elm Street; P.O. Box 666
Cumberland, Wisconsin 54829
Phone (715) 822-2415 Fax (715) 822-2223
1-800-345-6007
www.ardisam.com

CALIFORNIA PROPOSITION 65 WARNING

Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.




OWNER'S RESPONSIBILITY


Accurate assembly and safe and effective use of the auger is the owner's responsibility.

1. Read and follow all safety instructions.
2. Carefully follow all assembly instructions.
3. Maintain the auger according to directions and schedule included.
4. Ensure that anyone who uses the auger is familiar with all controls and safety precautions.

CAUTIONS AND IMPORTANT NOTES

Two symbols which draw attention to information of special interest appear throughout this manual. These comments range in importance from helpful hints to warnings about risk of personal injury. Please take the time to read and understand them.

 CAUTION
Indicates a situation which may cause personal injury or damage to the auger or property.

 IMPORTANT
Provides helpful information for proper assembly, operation, or maintenance of your auger.

IMPORTANT SAFETY PRECAUTIONS

Please read this section carefully. Operate auger according to safety instructions and recommendations outlined here and inserted throughout the text. Make sure anyone who uses the auger has read the instructions and is familiar with the controls.



This symbol points out important safety instructions which if not followed could endanger your personal safety. Read and follow all instructions in this manual and any others provided with this equipment.

1. The earth blade is very sharp. Use extreme caution when drilling a hole or replacing the blade.
2. Do not carry the auger between holes with the engine running.
3. The auger should not rotate when the engine is idling. If it does rotate when engine is idling, contact Ardisam, Inc. for instructions.
4. Always keep hands and feet clear of rotating auger.
5. Do not wear loose clothing while operating the power auger.
6. Do not allow children to operate this power auger. Do not allow adults to operate the auger without proper instruction.
7. Do not operate any power equipment under the influence of alcohol or drugs.



REGISTRATION FORM

Complete and return. Your auger has a serial number decal located on side of engine directly above the carburetor. Record this number and the model number in the space provided on page 3 of this manual. You will need these numbers if you order parts. Fill out and mail the registration card located in your parts packet. Warranty is valid only if your completed registration card is received by Ardisam, Inc., at time of purchase.

SPARK PLUG INSTALLATION

If your powerhead does not have the spark plug already installed for you. You will have to install it following the instructions given below.

1. Locate the spark plug in the parts packet.
2. With powerhead laying on side labeled "**THIS SIDE UP WHEN NOT IN USE,**" place spark plug in spark plug hole. For replacement use Champion RJ-19LM only.

NOTE: A resistor spark plug must be used for replacement.

3. Turn by hand until snug.
4. Use a wrench or socket to tighten up.

OPERATION



CAUTION

Please do not start your auger until you have read the Engine Manual that came with your engine, and the section in this manual titled Safety. If you have read these, follow the steps below to start your auger. Always perform pre-start checklist before starting the engine.

1. Read engine manual and follow instructions for fuel type, starting, etc.
2. The clutch will transfer maximum power after about two hours of normal operation. During this break-in period clutch slippage may occur. The clutch should be kept free of oil or other moisture for efficient operation. Each unit is tested at the factory, but is not operated for the full break-in period.
3. Your auger should be operated no more than 20 degrees in any direction during continuous use and limited to 30 degrees intermittently. Recommended for adequate lubrication and fuel delivery.



CAUTION

It is recommended that the unit not be tilted at more than a 30° angle from the upright position. Failure to do so can cause fuel and/or oil leakage.

4. When digging in heavy soil, pump the unit with an up and down motion in the hole for every one foot of depth.
5. Never run engine indoors. Exhaust fumes are deadly.
6. Do not use an earth auger in ice.



PRE-START CHECKLIST

1. Read and understand the engine manual and operator's manual that came with your unit.
2. Fill oil sump or check oil level. Check oil level often during engine break-in.
3. Fill fuel tank. Use unleaded, regular gasoline.



NEVER MIX OIL WITH GASOLINE.

CAUTION

Never add gas when engine is running or hot from operation. Never fill the tank indoors. Do not smoke when filling fuel tank.

CAUTION

Never fill fuel tank completely. Fill tank to 1/2" below bottom of filler neck to provide space for fuel expansion. Wipe any fuel spillage from engine and equipment before starting engine.

4. Be sure spark plug wire is attached to spark plug.

STARTING AND STOPPING

CAUTION

Do not hold throttle lever wide open while starting. Loss of control of auger could result.

CAUTION

Never run engine indoors or in enclosed, poorly ventilated areas. Engine exhaust contains carbon monoxide, an odorless and deadly gas.

CAUTION

Keep hands, feet, hair and loose clothing away from any moving parts on engine and equipment.

CAUTION

Temperature of muffler and near by areas may exceed 150° F. Avoid these areas.

To Start Engine:

1. Open fuel shut-off valve.
2. Flip the on/off switch to **on** position.
3. Move throttle control lever to **start**.
4. Push primer three (3) times. Wait about two (2) seconds between each push. In cold weather (55° F or below) push five (5) times.

NOTE: Do not use primer to restart a warm engine after a short shut down.

5. Grasp starter handle and pull rope out, slowly, until it pulls slightly harder. Let rope rewind slowly. Then pull rope with a rapid full arm stroke. Let rope return to starter slowly.

NOTE: If engine fails to start after three (3) pulls, repeat instruction 2.

To Stop Engine:

1. Flip the on/off switch to the **off** position.
2. Close fuel shut-off valve.

CAUTION

Disconnect spark plug wire from spark plug and attach it to retaining post.

CAUTION

Never store engine with fuel in tank indoors or in enclosed, poorly ventilated areas, where fuel fumes may reach an open flame, spark or pilot light.



MAINTENANCE AND STORAGE

CAUTION

To prevent accidental starting:
Engine must be turned off and cool, and spark plug wire must be removed from spark plug before checking and adjusting engine or equipment.

ENGINE MAINTENANCE

CAUTION

Do not operate auger before reading the engine manual provided in the parts packet.

MAINTENANCE AND STORAGE SAFETY

1. Always allow muffler to cool before filling fuel tank.
2. When storing for over one (1) month, use gas stabilizer in fuel.
3. Do not fill gas tank indoors or when engine is running or is hot.
4. The gear case has four (4) oz. of grease installed at the factory. It is recommended that once a year the gear case be split and the grease level checked. Add grease only if level of grease is below top of the gears. **DO NOT OVERFILL.**
5. For cold weather operation, store the unit in a cool environment. Transferring the unit from a warm to a cold place can cause the build up of harmful condensation.

IMPORTANT

Engine can overheat and become damaged if debris blocks the cooling fins or recoil housing.

Refer to the engine manual included in your parts packet for information on engine maintenance. Your engine manual provides detailed information and a maintenance schedule for performing the following tasks:

1. Check oil level every five (5) operating hours and before each use.
2. Change oil after first two (2) operating hours and every 25 operating hours thereafter, more often if operated in extremely dusty or dirty conditions. Change oil while engine is still warm from recent running.
3. Frequently remove dirt and debris from cooling fins, air intake screen, levers and linkage. This will help ensure adequate cooling and correct engine speed.
4. Check air cleaner.

IMPORTANT

Never run engine without complete air cleaner installed on engine.

5. Check spark plug yearly or every 100 operating hours.
6. Check engine and auger often for loose nuts and bolts.

STORAGE



CAUTION


Do not store auger with fuel in tank indoors or in enclosed, poorly ventilated areas, where fuel fumes may reach an open flame, spark, pilot light or an ignited object. Drain fuel outdoors away from any ignition sources. Use only approved fuel containers.



CAUTION

FOR LONG TERM STORAGE:

Close fuel shut-off valve and store powerhead in an upright position. Failure to do so can cause oil leakage over a prolonged period.



Follow the steps below to prepare your auger for storage. Read your engine manual for detailed instructions on preparing the engine for storage.

1. Run with gas stabilizer in fuel. Screen in carburetor will glaze shut if gas stabilizer is not used before storage.
2. Drain the fuel system. Run the engine until it stops.
3. Change oil.
4. Remove spark plug, pour one (1) ounce of clean engine oil into spark plug hole. Cover hole with a rag. Pull starter handle slowly several times to distribute oil. Install spark plug. Do not connect spark plug wire.
5. Clean entire auger.
6. Store your auger in a clean, dry building that is inaccessible to children.



SERVICE, TROUBLESHOOTING AND REPAIR

SERVICE INFORMATION

IMPORTANT

IN CASE OF A SERVICE PROBLEM, DO NOT SEND UNIT BACK TO RETAILER. CONTACT ARDISAM, INC. AT 1-800-345-6007.

At Ardisam, we build quality and durability into the design of our products; but no amount of careful design by us, and careful maintenance by you, can guarantee a repair-free life for your auger. Most repairs will be minor, and easily fixed by following the suggestions in the troubleshooting guide in this section. The guide will help you pinpoint the causes of common problems and identify remedies.

For more complicated repairs, you may want to rely on your retailer or an authorized mechanic (contact your retailer for a list of authorized mechanics in your area). A parts catalog is included in this section.

We will always be glad to answer any questions you have, or help you find suitable assistance. To order parts or inquire about warranty, call or write us at the address found in the next column under the section ordering repair parts.

ORDERING REPAIR PARTS

Parts can be obtained from the store where your auger was purchased or direct from the factory. To order from the factory, call or write to:



ARDISAM, INC.
1690 Elm Street; P.O. Box 666
Cumberland, Wisconsin 54829
Phone (715) 822-2415 Fax (715) 822-2223
1-800-345-6007
www.ardisam.com

Please include the following information with your order:

1. Part numbers
2. Part description
3. Quantity
4. Model number and serial number



TROUBLESHOOTING


⚠ CAUTION

Practice safety at all times. Engine must be turned off and allowed to cool, and spark plug wire must be disconnected before attempting any maintenance or repair.

Problem	Possible cause	Remedy/Action
Engine will not start	<ol style="list-style-type: none"> 1. Power switch off 2. Spark plug wire disconnected 	<ol style="list-style-type: none"> 1. Flip switch to on position 2. Connect spark plug wire to spark plug
Engine runs rough, floods during operation	<ol style="list-style-type: none"> 1. Dirty air cleaner 2. Carburetor out of adjustment 	<ol style="list-style-type: none"> 1. Clean or replace air cleaner 2. Take to authorized Tecumseh service center
Engine is hard to start	<ol style="list-style-type: none"> 1. Stale fuel 2. Spark plug wire loose 3. Dirty carburetor 	<ol style="list-style-type: none"> 1. Drain old fuel and replace with fresh. Use gas stabilizer at end of season 2. Make sure spark wire is securely attached to spark plug 3. Clean carburetor, use gas stabilizer, new gas can
Engine misses or lacks power	<ol style="list-style-type: none"> 1. Clogged fuel tank 2. Clogged air cleaner 3. Improper carburetor adjustment 4. Spark plug dirty, improper gap, or wrong type 	<ol style="list-style-type: none"> 1. Remove and clean 2. Clean or replace 3. Take to authorized Tecumseh service center 4. Replace spark plug and adjust gap
Auger turns at idle	<ol style="list-style-type: none"> 1. Idle speed too high 2. Broken clutch spring 	<ol style="list-style-type: none"> 1. Adjust idle speed lower 2. Replace both springs
Auger turns, but has no power	<ol style="list-style-type: none"> 1. Carburetor out of adjustment 2. Broken transmission 3. Worn clutch shoes 4. Worn engine lower seal 	<ol style="list-style-type: none"> 1. Take to authorized Tecumseh service center 2. Return to factory 3. Replace clutch shoes and springs 4. Take to authorized Tecumseh service center
Auger cuts slowly	<ol style="list-style-type: none"> 1. Damaged point 	<ol style="list-style-type: none"> 1. Buy a new fishtail point
Engine runs, then quits	<ol style="list-style-type: none"> 1. Screen in carburetor plugged 	<ol style="list-style-type: none"> 1. Clean screen, use gas stabilizer, clean gas can



EARTHQUAKE MODEL 9800



EARTHQUAKE MODEL 9800



MINIMUM ORDER \$10.00

<u>PART #</u>	<u>DESCRIPTION</u>	<u>QTY.</u>	<u>PART #</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
60G56	Nut-Hex, 5/16-18, Two Way Reversible Locknut	4	9016	Clutch Drum	1
105	Nut-Hex, Nyloc, #10-32	1	9038	Gear Case w/ Bearings, (upper half)	1
420	Bolt, C-Bore, High Torque, 5/16-24NF x 3/4"	4	9211	Handle Grip, 7/8" ID	4
503	Bolt-Hex Hd, 5/16-18 x 1-1/2"	4	9214A	10T Pinion Gear	1
8906WC	Screw-Machine, #10-32 x 1-1/4"	1	9805A	Throttle Control Cable Assembly	1
8912	44T Gear	1	9810	Main Handlebar Assembly, 2-Person	1
8913	Shaft, Output, 7/8"	1	9811	Switch, On-Off (Not Shown)	1
8914	48T Gear	1	9814	7T Pinion Gear, Threaded	1
8915	Dowel Pin, 1/4" x 1/2", Hardened Steel	2	9825	Centrifugal Clutch Rotor	1
8919	Gasket	1	9837A	Mount Ring-Aluminum	1
8922	Ball Bearing	3	63124	Extension Spring, Throttle	1
8923	Ball Bearing	2	98101	Handle, 1-Hole	3
8924	Snap Ring	3	98102	Handle, 2-Hole, Throttle Control	1
8929	Bolt-SHCS, 1/4-20 x 1-1/2" (gear case bottom to gear case top)	2	GCA38	Gas Cap	1
8935	Bolt-SHCS, 1/4-20 x 2-1/2" (gear case to handlebar plate)	4	GT38HP	Gas Tank	1
8939	Gear Case w/ Bearings, (lower half)	1	LEV12038	Gas Engine, Tecumseh 3.8 HP	1
			WK6	Woodruff Key, #6	1



ARDISAM, INC.

1690 Elm Street; P.O. Box 666
Cumberland, Wisconsin 54829

Phone (715) 822-2415 Fax (715) 822-2223

1-800-345-6007

www.ardisam.com