

Hub Blinds

Yukon Tracks offers a full line of Engineered Outdoor Gear. We appreciate your purchase of one of our world class Hub Blinds. Follow these few simple instructions and your Hub Blind will be sure to give you many years of trouble free pleasure. Instructions should be kept in a safe place and reviewed at least annually.

If for any reason you have a problem with your product, DO NOT return to the retailer, contact the Yukon Tracks customer service department at 800-345-6007 for assistance.

SET-UP INSTRUCTIONS:

1. Remove the ground blind from backpack carrying bag by unzipping the bag completely.
2. Lay the blind flat on the ground and be completely sure there is no material twisted or overlapping the ends of any poles. **SEE FIGURE 1.**
3. Grab the webbing loop sewn on to the eyelet, located in the center of the roof and pull upward so the roof portion pops open. **SEE FIGURE 2.**
4. Lift the roof up so that you can grab any one of the hubs located in the center of each wall. Grab the webbing loop sewn on to the eye lit and pull out as you did in step 3. **SEE FIGURE 3.**

NOTE: Place your foot on the ground skirt to help hold the blind in place when popping open the walls.

5. Proceed by walking around entire blind and pulling on each walls sewn on webbing loop to pop out each wall until all sides are popped out. **SEE FIGURES 4 & 5.**
6. Your blind should be standing up completely as in **FIGURE 6.** You may now proceed by anchoring the blind to the ground using the provided ground stakes and rope. Tie-down loops are sewn in each corner and each side. Use the provided rope and tie one end to the hub eye lit on each wall, and the other end to a ground stake.

NOTE: Window configurations can now be set. On Elite Series, native brush can be placed in brush holders located on four upper corners.




FIGURE 1



FIGURE 2



FIGURE 3



FIGURE 4

ASSEMBLY AND USE INSTRUCTIONS FOR THE FOLLOWING MODELS:

RIVERS EDGE® FALL CAMO BLINDS
ENFORCER (AV164)
DISPATCHER (AV148)
EVADER (AV163)

RIVERS EDGE® SPRING CAMO BLINDS
ENFORCER (AV174)
DISPATCHER (AV178)
EVADER (AV173)

RIVERS EDGE® ELITE FALL CAMO BLINDS
ENFORCER ELITE (AV169)
DISPATCHER ELITE (AV167)

BACKLANDS WEST CAMO BLINDS
DISPATCHER ELITE (AV172)
ENFORCER ELITE (AV175)

WARNING

READ, UNDERSTAND AND FOLLOW ALL ASSEMBLY, INSPECTION, & USE INSTRUCTIONS PROVIDED BEFORE EACH USE. FAILURE TO FOLLOW WARNINGS AND INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.

KNOW THE LOCATION OF EACH HUNTER IN YOUR PARTY AT ALL TIMES AND BE AWARE OF ANY ONE ELSE HUNTING IN THE AREA TO AVOID ACCIDENTS.

USE CAUTION WHEN SETTING UP. KEEP AWAY FROM BODY AND FACE. KEEP CLEAR OF OTHER PEOPLE WHILE SETTING UP.

THIS PRODUCT IS NOT FIREPROOF. THE FABRIC WILL BURN IF IT COMES INTO CONTACT WITH AN OPEN FLAME OR FUEL SOURCE. NO HEATER OR OPEN FLAME SHOULD BE USED INSIDE OR NEAR THIS BLIND.

NEVER ALLOW CHILDREN OR ADULTS TO USE LIGHTED CANDLES, MATCHES, OR OTHER SOURCES OF FIRE NEAR THIS PRODUCT.

NEVER USE ANY DEVICES THAT PRODUCE FUMES WHILE INSIDE OF BLIND. SUCH DEVICES COULD RESULT IN CARBON MONOXIDE POISONING, INJURY, OR DEATH.

WHEN GUN HUNTING, YOU SHOULD ALWAYS ATTACH THE BLAZE ORANGE SAFETY CAP (NOT INCLUDED) PART NO. AV180 TO THE ROOF OF BLIND FOR ADDED SAFETY FROM OTHER HUNTERS.

UV WARNING

ULTRAVIOLET LIGHT BREAKS DOWN LIGHTWEIGHT FABRIC FIBERS. THE MATERIAL WILL FADE, LOSE STRENGTH AND EVENTUALLY DISINTEGRATE IF LEFT IN PROLONGED SUNLIGHT. TO EXTEND THE LIFE OF YOUR YUKON TRACKS GROUND BLIND, AVOID LEAVING IT OUT IN DIRECT SUNLIGHT FOR EXTENDED PERIODS OF TIME. SET-UP IN A SHADY AREAS WHENEVER POSSIBLE. FADING OR DISCOLORING OF BLIND IS NOT COVERED UNDER YOUR WARRANTY.

GetYukonTracks.com

800-345-6007 • Fax (715) 822-4180
 E-mail: info@ardisam.com



GetYukonTracks.com

OMAVHUBS
 Rev. Date 3/10/08
 © 2008 Ardisam, Inc.
 All Rights Reserved.

Hub Blinds



FIGURE 5



FIGURE 6

TAKE DOWN INSTRUCTIONS:

1. Remove all ropes and ground stakes and store them in the provided pouch. On Elite Series, remove native brush. Zip up all windows, **but leave door unzipped!**
2. Using your hand, push the center hub on roof until it collapses inward. **SEE FIGURE 7.**
3. Continue pushing each wall inward until all walls are collapsed. **SEE FIGURE 8.**
4. Blind will be back in its flat stage just as it was when it was unfolded out of the backpack bag. Gather all corners of the blind and fold together. **SEE FIGURE 9.** Do not force the blind when folding. Watch for entanglement of poles.
5. Place folded up blind back into the backpack carrying case with the hubs towards the bottom end of bag always. Place ground stake and rope pouch into backpack as well.

MAINTENANCE INSTRUCTIONS:

1. Never put blind away wet. Always put away dry to avoid mildew.
2. Take down blind when not in use to avoid unnecessary damage and fading.
3. Seal the seams with seam sealer and the walls and roof with silicon spray if leaking occurs.
4. Use extra tie-downs during excessive winds.



FIGURE 6



FIGURE 7



FIGURE 8



FIGURE 9

WARNING

READ, UNDERSTAND AND FOLLOW ALL ASSEMBLY, INSPECTION, & USE INSTRUCTIONS PROVIDED BEFORE EACH USE. FAILURE TO FOLLOW WARNINGS AND INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.

THIS PRODUCT IS FOR HUNTING PURPOSES ONLY! IT IS NOT TO BE USED AS A CAMPING TENT OR FOR ANY OTHER FUNCTION.

THIS BLIND IS DESIGNED FOR PORTABILITY. DO NOT LEAVE BLIND SETUP OUTDOORS WHEN NOT IN USE.

DO NOT USE FIREARMS TO SHOOT THROUGH THE REMOVABLE SHOOT-THROUGH MESH WINDOWS. THE SHOOT-THROUGH WINDOWS ARE INTENDED FOR ARCHERY USE WITH FIXED BLADE BROAD HEADS ONLY!

NEVER ALLOW CHILDREN TO PLAY IN THIS PRODUCT WITHOUT ADULT SUPERVISION. TO DO SO COULD CAUSE SERIOUS INJURY OR DEATH.

NEVER ALLOW THE MATERIAL TO COVER YOUR FACE. THIS MATERIAL CAN CAUSE SUFFOCATION AND DEATH IF IT IS PLACED OVER FACE.

UV WARNING

ULTRAVIOLET LIGHT BREAKS DOWN LIGHTWEIGHT FABRIC FIBERS. THE MATERIAL WILL FADE, LOSE STRENGTH AND EVENTUALLY DISINTEGRATE IF LEFT IN PROLONGED SUNLIGHT. TO EXTEND THE LIFE OF YOUR YUKON TRACKS GROUND BLIND, AVOID LEAVING IT OUT IN DIRECT SUNLIGHT FOR EXTENDED PERIODS OF TIME. SET-UP IN A SHADY AREA WHENEVER POSSIBLE. FADING OR DISCOLORING OF BLIND IS NOT COVERED UNDER YOUR WARRANTY.

HUB BLIND COMPONENTS:

- 48717 Enforcer fall window
- 48783 Enforcer spring window
- 48862 Enforcer Elite window
- 48505 Enforcer Elite Backlands West window
- 48713 Enforcer pole 50" long
- 48718 Enforcer fall backpack
- 48784 Enforcer spring backpack
- 48507 Enforcer Elite Backlands West backpack
- 48711 Dispatcher fall window
- 48775 Dispatcher spring window
- 48865 Dispatcher Elite window
- 48504 Dispatcher Elite Backlands West window
- 48707 Dispatcher pole 42" long
- 48712 Dispatcher fall backpack
- 48776 Dispatcher spring backpack
- 48506 Dispatcher Elite Backlands West backpack
- 48705 Evader fall window
- 48779 Evader spring window
- 48701 Evader pole 37" long
- 48706 Evader fall backpack
- 48780 Evader spring backpack
- 48722 Ground stake
- 48723 Tie down rope

HUB BLIND ACCESSORY:

- AV180 Blaze cap